

INSTALLATION INSTRUCTIONS



1557 - TO SUIT NISSAN NAVARA D22 4WD WITHOUT BUMPER 86-ON **PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN**

WARNING : 1. Do not drill, cut weld or otherwise modify the towbar.

2. If you are using electric welding on a motor vehicle, always check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could destroy any onboard computers. If in doubt, check with the vehicle's manufacturer.


1. Ensure all hardware items have been included.
2. Lift towbar up into position locating most rearward holes in towbar side arms with large holes in bottom face of chassis.
3. Fit bolts and loose plates.
4. Using two most forward holes in towbar side arms as a guide drill remaining two holes and fit loose plates, bolts, spring washers and nuts.
5. Tighten all bolts to torque listing below.
6. Towbar rating sticker to be conspicuously located on inside rear end of the driver's door.
(see diagram below)

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8

FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.



PLEASE NOTE: You must remove the lug unless you are actually towing if it obscures your number plate. Failure to do so may result in a fine.

IMPORTANT: Please see over for safety chain hook-up procedure.

1557 - TO SUIT NISSAN NAVARA 4WD WITHOUT BUMPER 86-ON

